THE LAWN MOWER™ 4.0 PRO

LIFT HERE

Customer service

UK | Email us at uk@manscaped.com or visit uk.manscaped.com/pages/help.
DE | Kundendienst @manscaped.com oder besuche eu.manscaped.com/de/pages/help.
FR | Service à la clientèle eu.fr@manscaped.com ou rendez-vous sur eu.manscaped.com/fr/pages/help.
ES | Atención al cliente eu.es@manscaped.com o vete a eu.manscaped.com/es/pages/help.
IT | Assistenza clienti eu@manscaped.com o vai su eu.manscaped.com/pages/help.
NL | Klantenservice eu@manscaped.com of bezoek eu.manscaped.com/pages/help.
PT | Atendimento ao cliente eu@manscaped.com ou visite eu.manscaped.com/pages/help.
AU | Email us at au@manscaped.com or go to au.manscaped.com/pages/help.
AR | راسلنا عبر البريد الإلكتروني على eu@manscaped.com أو تفضل بزيارة mena.manscaped.com/pages/help

MANSCAPED.COM

RY: Hunt Group BV, Kroonweel 2, 6003 EP Weert, Netherlands.
RP UK: Alara Group UK Ltd, 78 Parsonage Drawe, Great Dunmow, CM6 3AT, UK

IMPORTANT SAFETY INSTRUCTIONS

For household use only. When using an electric product, always follow basic precautions, including the following: **Read all instructions before using The Lawn Mower™ 4.0 Pro trimmer.** SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

WARNING

To reduce the risk of burns, fire, electric shock, or injury:

- Use this product only for its intended household use as described in this manual.
- This trimmer is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the trimmer by a person responsible for their safety. Children should be supervised to ensure that they do not play with the trimmer.
- This trimmer is intended to cut hair and cut or skin if not used carefully. Do not use attachments with sharp edges or points.
- This trimmer is for personal use only. Do not use it on animals or other with others.
- Do not use the trimmer if the trimmer, foil, blade/s are dull.
- Use only an external supply with the following specifications: 5V 1A.
- Never use the trimmer if it has a damaged power cord or damaged power adapter. If it is dropped, or has been dropped in water, or after the charging cord has been damaged, take it to a authorized service center. Contact MANSCAPED™ customer service for information on where to take the trimmer.
- Keep the charging cord away from heated surfaces. Do not place anything heavy on or against the charging cord.
- To prevent possible damage to the power cord, do not wrap it around the product.
- This product is for use on human hair only. Do not use the product for any other purpose.
- Do not use the trimmer on animals, and never cover it in a moisture-free area. Make sure the cord is disconnected from the product.
- Do not use the trimmer in a wet or condensation. Only use in detachable cord.
- Charge, use, and store the product at a temperature between 5°C to 35°C (41°F / 95°F). The normal temperature range for charging the battery is 0-40 °C.
- Do not expose the trimmer to open fire and do not expose them to direct sunlight or excessive temperatures.
- Do not use the trimmer abnormally hot or smelly. Changes color or if charging takes longer than usual, stop using and charging the product and contact support.
- Do not place trimmers or their batteries in a microwave oven or an induction cooker.
- Do not use the trimmer if damaged. Damaged the trimmer or battery to prevent batteries from heating up or releasing toxic or explosive gas. Damaged trimmers include overheatings, or reverse charge batteries.
- If batteries are damaged or leaking, avoid contact with the liquid. If in contact, rinse immediately rinse well with water, and seek medical care.
- Keep the trimmer/s/ away from of hot, hair, and sharp objects.
- Never drop or insert any object into any opening. Do not operate or plug in trimmer when service/ service/ products are being used or if the product is not functioning properly. Always check the blade and trimming guard before using the trimmer. Do not use the trimmer if the blade or guard is damaged, as injury may occur.
- Always store the trimmer, accessories, and power cord in a moisture-free area. Make sure the cord is disconnected from the trimmer.

IMPORTANT: This trimmer contains one Li-ion battery that is non-replaceable. When the battery reaches the end of its useful life, it should be properly disposed of. Charge units with the provided USB-C cable and a Safety Extra Low Voltage (SELV) compliant power supply matching the marking on the trimmer. Do not operate the trimmer into water while charging. Do not charge in wet, damp, or condensation. Do not charge in a moisture-free area. Make sure the cord is disconnected from the trimmer. Do not use the trimmer in a wet or condensation. Only use in detachable cord.

Suitable for use in a bath or shower.

Suitable for cleaning under an open tap/faucet.

WARNING: Detach the hand-held part from the charging cord before cleaning it in water.

DANGER

To reduce the risk of electric shock:

- Do not touch for a trimmer, if connected to a power outlet, that has fallen into water. Unplug immediately.
- Do not place or store the charging cord where it can fall or be pulled into a tub or sink. Do not place in water or other liquids.
- Always unplug from the electrical outlet immediately after charging.
- Always unplug the trimmer from the electrical outlet before cleaning it in water.

EUROPEAN UNION - DISPOSAL INFORMATION

This symbol means that according to local laws and regulations your product and/or its battery must be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection of and recycling your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. Visit **https://manscaped.com/pages/recycling** for more information.

The Lawn Mower™ 4.0 Pro trimmer is designed in California, USA and assembled in China. Patented by MANSCAPED, Inc., San Diego, CA 92101. © 2024 Manscaped, LLC. All Rights Reserved. MANSCAPED®, The Lawn Mower™ 4.0 Pro®, are trademarks of MANSCAPED, LLC, registered in the U.S. and other countries.

DE
Wichtige Sicherheitshinweise

Nur für den Hausgebrauch. Befolge bei der Verwendung eines elektrischen Produkts immer die grundlegenden Vorsichtsmaßnahmen, einschließlich der folgenden: Lesen Sie alle Anleitungen vor der Verwendung des The Lawn Mower™ 4.0 Pro Trimmers alle Anweisungen. Bewahre diese Hinweise zum späteren Nachschlagen auf.

WARNHINWEIS

Um das Risiko von Verbrennungen, Feuer, Stromschlägen oder Verletzungen zu verringern:

- Verwenden Sieses Produkt nur für den in diesem Handbuch beschriebenen Zweck.
- Dieser Trimmer ist nicht für Personen (einschließlich Kinder) mit eingeschränkten körperlichen, sensorischen oder geistigen Fähigkeiten oder mangelnder Erfahrung und Kenntnissen bestimmt, es sei denn, sie wurden von einer für ihre Sicherheit verantwortlichen Person beaufsichtigt oder in den Gebrauch des Trimmers eingewiesen. Kinder sollten beaufsichtigt werden, um sicherzustellen, dass sie nicht mit dem Gerät spielen.
- Der Trimmer ist dazu bestimmt, Haare zu schneiden und bei Nichtbeachtung oder unsachgemäßer Verwendung kann zu Verletzungen führen. Verwenden Sie keine Aufsatzteile mit scharfen oder spitzen Kanten.
- Dieser Trimmer ist nur für den persönlichen Gebrauch bestimmt. Nicht zur Pflege von Tieren oder anderen Personen verwenden.
- Verwenden Sie den Trimmer nicht, wenn die Trimmer und Klingen stumpf sind.
- Verwenden Sie nur eine externe Stromversorgung mit den folgenden Spezifikationen: 5V 1A.
- Verwenden Sieses Trimmer niemals, wenn das Netzkabel beschädigt ist oder das Netzkabel beschädigt ist, oder wenn das Netzkabel beschädigt ist, oder wenn das Netzkabel beschädigt ist. Wenden sich an den Kundendienst von MANSCAPED™, um zu erfahren, ob Sie das Produkt zur Reparatur bringen können.
- Halten Sie Lebensmittel von heißen Oberflächen fern. Legen Sie nichts Schweres auf das Ladekabel oder darauf.
- Wickeln Sie das Netzkabel nicht um das Produkt, um mögliche Schäden am Netzkabel zu vermeiden.
- Dieses Produkt ist nur für die Verwendung bei menschlichem Haar vorgesehen. Das Produkt für keinen anderen Zweck verwenden.
- Verwenden Sie den Trimmer nicht an Tieren, und niemals in feuchtigkeitsfreier Umgebung. Stellen Sie sicher, dass das Kabel vom Trimmer getrennt ist.
- Verwenden Sie den Trimmer nicht in einer feuchten oder kondensierenden Umgebung. Nur für abnehmbare Kabel verwendet.
- Laden, verwenden und lagern Sie das Produkt bei einer Temperatur zwischen 5°C und 35°C (41°F bis 95°F). Der normale Temperaturbereich für das Aufladen des Akkus beträgt 0-40 °C.
- Setzen Sie den Trimmer nicht offenem Feuer aus und vermeiden Sie es, direkt Sonnenlicht oder extreme Temperaturen ausgesetzt zu werden.
- Verwenden Sie den Trimmer nicht übermäßig heiß oder stinkend. Farbwechsel oder wenn das Laden länger dauert als gewöhnlich dauert, den Gebrauch einstellen und das Produkt einstellen und uns kontaktieren.
- Trimmer oder deren Akkus nicht in Mikrowellen- oder Induktionskochern platzieren.
- Den Trimmer oder die Akkus nicht öffnen, durchbohren, durchstechen, beschädigen oder auseinanderbauen. Wenn die Akkus undichtet oder entlaufen lose, pflege oder gebrauche Quelle freigesetzt werden. Die Akkus nicht kurzschließen, in Wasser oder Flüssigkeiten eintauchen oder ins Feuer werfen. Die Akkus nicht mit anderen Akkus oder Kontakt mit Haut oder Augen verbinden. Sollte dies der Fall sein, sofort mit Wasser ausspülen und ärztlichen Rat erholen.
- Halte die Lufteffnungen frei von Fusen, Haaren und anderen Gegenständen.

Wenn der Trimmer, Folie/n oder Klinge/n stumpf sind, den Trimmer nicht verwenden.

- Verwenden Sie den Trimmer nicht, wenn die Klinge oder Schutzkappe beschädigt ist, um Verletzungen zu vermeiden.
- Verwenden Sie nur Ersatzteile und Zubehör, die vom Hersteller empfohlen werden.
- Verwenden Sie den Trimmer nicht, wenn Sie müde sind oder unter Einfluss von Drogen, Alkohol oder Medikamenten stehen.
- Lagern Sie den Trimmer und das Zubehör an einem trockenen Ort und bewahren Sie das Netzkabel nicht zusammengerollt auf