Item : NEXXT 3 in 1 Vacuum Cleaner (600W)

Style : 1C Instr.
Packing Size : 210 x 120mm
Date : 02 April 2024
Version : 2024.0402_**V1**

NEXXT
3 in 1 Vacuum Cleaner 600W

NEXXT

USER MANUAL

Please read this instruction manual carefully before use

A. Safety Instructions

- Check that the voltage of the main circuit corresponds with the rating of the appliance before operating.
- If the supply cord or appliance is damaged, stop using the appliance immediately and seek advice from the manufacturer, its service agent or a similarly qualified person.
- DO NOT let the cord hang over the edge of a table or counter or let it come into contact with any hot surfaces.
- DO NOT carry the appliance by the power cord.
- The use of accessory attachments is not recommended by the appliance manufacturer apart from those supplied with this product. DO NOT use extension cords with the appliance.
- DO NOT pull the plug out by the cord as this may damage the plug and/or the cable
- Switch off at the wall socket then remove the plug from the socket when not in use or before cleaning.
- Switch off and unplug before fitting or removing tools/ attachments, after use and before cleaning.
  Close supervision is necessary when any appliance is used by or near children.
- Children should not play with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensor or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a Safeway and understand the hazards involved.
- Cleaning and user maintenance should not be undertaken by children without supervision.

B. Technical Details

Product Model	: 2CO140324-1	N.W.	: 2.3KG
Rated voltage	: 220-240V	Capacity	: 0.5L
Rated power	: 600W	Product Size	: 240*135*1080cm

C. Product Accessories

(1) Switch	(5) Telescopic Tube
(2) Dust Cup Release Button	(6) Floor Brush
(3) Dust Cup	(7) Crevice Nozzle
(4) Telescopic Tube Button	(8) Round Brush

D. Installation Guide

Please do not insert the plug into the power source during installation

1. Place the Hepa filter into the dust cup and tighten.

2. The dust cup is connected to the main body.

3. Insert the telescopic aluminum tube into the main body.
4. Insert the floor brush into the tube.

E. Important

Do NOT push the power cord or machine.

Forbidden to use machine to suck the lighted cigarette or hot ask.

Forbidden to use machine to suck the object with liquid.

Do NOT use machine to suck sharp object.

F. Trouble Shooting

PROBLEM	PROBLEM REASON	POSSIBLE SOLUTION
Handheld vacuum cleaner does not work.	No power socket.	Check fuse or breaker, replace fuse / reset breaker.
Handheld vacuum cleaner cannot pick-up dusk, suction power become weak.	Dust container is full. Dust filter needs cleaning or replacement.	Empty dust container. Remove dust filter assembly and check for object(s) in suction inlet and remove. Clean or replace dust filter assembly.
Dust leak from Handheld vacuum cleaner.	Dust container is full. Dust filter is not installed correctly. Puncture / hole in dust filter.	Empty dust container. Review the dust filter assembly installation instructions. Replace dust filter assembly.
Hear strange noise when the appliance work.	Check whether the floor brush and dust filter is blocked by big dust; check whether dust container is full.	Stop to use the appliance right now; clean the dust assembly and floor brush, empty the dust container. If the problem cannot disappear, please contact a service agent.

Lees voor gebruik deze gebruiksaanwijzing aandachtig door

A. Veiligheidsinstructies

Houd het ver van voorwerpen of vloeistoffen die gemakkelijk te vlam vatten of om brand of explosie tijdens het gebruik te voorkomen.

- Controleer vóór gebruik of de spanning van het hoofdcircuit overeenkomt met het vermogen van het apparaat.
- Als het netsnoer of het apparaat beschadigd is, stop dan onmiddellijk met het gebruik van het apparaat
- Vraag advies aan de fabrikant, zijn serviceagent of een vergelijkbaar gekwalificeerd persoon.
- Laat het snoer NIET over de rand van een tafel of aanrecht hangen en laat het NIET in contact komen met hete oppervlakken.
- Draag het apparaat NIET aan het netsnoer.
- Het gebruik van accessoires wordt niet aanbevolen door de fabrikant van het apparaat, behalve de accessoires die bij dit product worden geleverd. Gebruik GEEN verlengsnoeren met het apparaat.
- Trek de stekker NIET aan het snoer uit het stopcontact, omdat dit de stekker en/of de kabel kan beschadigen.
- Schakel het apparaat uit via het stopcontact en verwijder vervolgens de stekker uit het stopcontact als u het apparaat niet gebruikt of voordat u het schoonmaakt.
- Schakel het apparaat uit en haal de stekker uit het stopcontact voordat u gereedschappen/hulpstukken aanbrengt of verwijdert, na gebruik en vóór het reinigen.
- Strikt toezicht is noodzakelijk wanneer een apparaat door of in de buurt van kinderen wordt gebruikt.
- Kinderen mogen niet met het apparaat spelen.
- Dit apparaat kan worden gebruikt door kinderen van 8 jaar en ouder en door personen met verminderde fysieke, sensorische of mentale capaciteiten of een gebrek aan ervaring en kennis, als ze onder toezicht staan of instructies hebben gekregen over het veilige gebruik van het apparaat en de mogelijke gevaren begrijpen.
- Reiniging en gebruikersonderhoud mogen niet door kinderen zonder toezicht worden uitgevoerd.

B. Technische gegevens

Product Model	: 2CO140324-1	N.W.	: 2.3KG
Voltage	: 220-240V	Capaciteit	: 0.5L
Spanning	: 600W	Product formaat	: 240*135*1080cm

C. Accessoires

(1) Aan Uit knop	(5) Telescopische steel
(2) Stofcontainer knop	(6) Vloerborstel
(3) Stofcontainer	(7) Hoek zuigmond
(4) Telescopisch steel stelknop	(8) Ronde borstel

D. Installatie

Steek tijdens de installatie de stekker niet in de stroombron.

1. Plaats het Hepa-filter in de stofbak en draai het vast.

2. De stofbak is verbonden met het hoofdgedeelte.

3. Steek de telescopische aluminium buis in het hoofdgedeelte.
4. Plaats de vloerborstel in de buis.

E. Belangrijk

Het snoert niet naar binnen duwen.

Zuig geen brandende sigaretten of as op.

Geen vloeistof opzuigen.

Geen scherpe voorwerpen opzuigen.

F. Problemen oplossen

Probleem	Mogelijke oorzaak	Mogelijke oplossing
Handstofzuiger werkt niet.	Geen stroom.	Check de zekering.
Het apparaat zuigt niet of is zwak.	Stofcontainer zit vol of filter schoonmaken.	Leeg de stofcontainer of neem de filter uit en controleer op voorwerpen in de zuigmond.
Stof lek uit het apparaat.	Stofcontainer zit vol of filter zit niet goed op zijn plaats.	Leeg de stofcontainer herplaats het filter.
Vreemd geluid tijdens het zuigen.	Check of de vloerborstel verstopt zit.	Stop met gebruik, maak het stoffilter schoon.

NEXXT

NEXXT is the innovative brand with high-quality gadgets for in and around the house. Opt for sustainable comfort with our inspiring articles and make your life easier, simpler, or more relaxed. Always at a competitive price. Because we believe in affordable innovation for modern living. NEXXT, the new ease.

Thank you for choosing one of our NEXXT products! Before you get started, we strongly recommend reading this entire manual carefully to prevent possible physical injury and damage to the product. We cannot be held responsible for the consequences of incorrect or faulty installation if the instructions in this manual are not followed meticulously. If you have any questions, encounter installation problems, or have doubts about safety, please feel free to contact us at info@conceptonlinebv.nl.

Imported by Concept Online BV NL- 3871MM-28