

# RAZER KRAKEN KITTY V2

MASTER GUIDE

Create your cutest stream persona in killer kitty style with the new **Razer Kraken Kitty V2**. Stand out and turns heads with unique kitty ears powered by Razer Chroma<sup>™</sup> RGB, as you put on a show with stream-reactive lighting and a crystal-clear mic.

# CONTENTS

1. WHAT'S INSIDE	3
2. WHAT'S NEEDED	4
3. LET'S GET YOU COVERED	4
4. TECHNICAL SPECIFICATIONS	5
5. SETTING UP YOUR RAZER KRAKEN KITTY V2	6
6. USING YOUR HEADSET	8
7. CONFIGURING YOUR RAZER KRAKEN KITTY V2 VIA RAZER SYNAPSE	10
8. SAFETY AND MAINTENANCE	23
9. LEGALESE	24

# 1. WHAT'S INSIDE

Razer Kraken Kitty V2



- A. Stream reactive kitty ears and earcups Powered by Razer Chroma<sup>™</sup> RGB
- B. Adjustable padded headband
- C. Hybrid fabric and leatherette cushions
- Important product information guide

- D. USB Type A cable connector
- E. Razer<sup>™</sup> HyperClear cardioid mic
- F. Volume control wheel
- G. Mic mute button

# 2. WHAT'S NEEDED

### PRODUCT REQUIREMENTS

USB Type A port

### **RAZER SYNAPSE / STREAMER COMPANION APP\* REQUIREMENTS**

- Windows<sup>®</sup> 10 64-bit (or higher)
- Internet connection for software installation

\*Razer Synapse with Chroma Connect module required.

# 3. LET'S GET YOU COVERED



Register your product and score exclusive benefits **razerid.razer.com/warranty** 



# 4. TECHNICAL SPECIFICATIONS

#### HEADPHONES

- Ears: Fixed Kitty Ears
- RGB: Razer Chroma<sup>™</sup> RGB (Ear and Earcups)
- Frequency response: 20 Hz 20 kHz
- Impedance: 32 Ohms
- Sensitivity: 92.5 dB SPL/mW@1KHz
- Drivers: Customized Dynamic 40mm Driver
- Inner ear cup diameter: 61 x 43mm
- Oval ear cushions: Full-ear fabric and plush leatherette
- Connection type: USB Type A

#### MICROPHONE

- Frequency response: 100 Hz 10 kHz
- Signal-to-noise ratio: ≥ 60 dB
- Sensitivity (@1 kHz): -42 dBV/Pa
- Pick-up pattern: Unidirectional

#### **ON-EARCUP CONTROLS**

- Volume up and down
- Mic mute on/off toggle

#### AUDIO USAGE

- Wired audio usage: USB Type A
- Surround sound: Only available on Windows<sup>®</sup> 10 64-bit (or higher)

# 5. SETTING UP YOUR RAZER KRAKEN KITTY V2

1. Connect your Razer headset to any of the USB ports on your PC.



2. On your device (if applicable), set the **Razer Kraken Kitty V2** as the default **Input** and **Output** device.



When using your headset with a compatible device, set Razer Kraken Kitty V2 as its default input and output device (if applicable).

Ŧ

# PERSONALIZE YOUR EXPERIENCE

Razer Synapse app\*

Customize your headset's lighting to your heart's content for an immersive gaming experience that's truly yours.

**1** Install Razer Synapse when prompted, or download the installer from <u>razer.com/synapse</u>

#### Razer Streamer Companion app\*

Add a new level of audience interaction by personalizing which colors and effects will react to your viewers' emotes, alerts, shout-outs, and more.



Install the Razer Streamer Companion app via Razer Synapse or download it directly from razer.com/ streamer-companion-app

# 6. USING YOUR HEADSET

### VOLUME CONTROL WHEEL

Rotate the Volume control wheel to increase or decrease the volume.



# RAZER HYPERCLEAR CARDIOID MIC

Bend the Razer HyperClear cardioid mic until it's parallel to your mouth.



Make sure the mic diaphragm is in front, and the air vent is facing away from your mouth. The recommended mic-to-mouth distance for optimal sound capture is 1.5 cm to 3 cm (0.59 to 1.18 in).

Press the mic mute button to mute or unmute the microphone.



# COMFORT

It's recommended to gently stretch the headset before placing it over your head to minimize headband stress; however, don't stretch the headset beyond its limits.

FOR GAMERS. BY GAMERS.™



# 7. CONFIGURING YOUR RAZER KRAKEN KITTY V2 VIA RAZER SYNAPSE

Internet connection is required for installation, updates, and cloud-based features. Registering for a Razer ID account is recommended but optional. All listed features are subject to change based on the current software version, the connected device(s), and supported apps and software.

### SYNAPSE TAB

The Synapse tab is your default tab when you first launch Razer Synapse. This tab allows you to navigate the Dashboard subtab.

#### Dashboard

The Dashboard subtab is an overview of your Razer Synapse, where you can access all your Razer devices, modules, and online services.



#### Modules

The Modules subtab displays all installed and available modules for installation.

SYNAPSE	AUDIO PROFILES		¢ – 🗆	×
< > DASHBO	ARD MODULES GLOBAL S	HORTCUTS		
AVAILABLE MODULES				
0	ALEXA The Amazon Alexa module brings full Alexa Voice integration to Synapse 3 for all Chroma enabled d active microphone and Amazon Alexa account.		CHROMA CONNECT $thm: thm: thm: thm: thm: thm: thm: thm: $	
0	CHROMA STUDIO Unlock advanced Razer Chroma <sup>14</sup> capabilities with that allows you to create multiple lighting effects across all your devices, while following the exact devices on your desktop. Manage all your Chroma and programs via the Chroma Apps tab	synchronized	CHROMA VISUALIZER $thm: thm: thm: thm: thm: thm: thm: thm: $	
PHILIPS hue	HUE Enter a new level of immersion with the Philips Hu as your Razer Chroma enabled devices sync with and let your gaming experience transcend the scr beyond your peripherals. Sync with your Philips H Hue tab	your Hue Bridge, een and go	MACRO Estimation of the second	

#### **Global Shortcuts**

Bind operations or Razer Synapse functions to custom key-combinations from any Razer Synapseenabled device inputs, which apply across all device profiles. Learn more about Profiles



• Only Razer Synapse-enabled device inputs will be recognized.

SYNAPSE AUDIO	PROFILES			¢	- 0	×
< > DASHBOARD	MODULES	GLOBAL SHORTCUTS				
	SHORTCL	TS	+			
	Global sho works for	rtcuts are custom key combinations that work across all device profiles. This featur tazer Synapse 3-enabled device inputs.	e only			
		+ ADD A SHORTCUT				

### AUDIO TAB

The Audio tab is the main tab for your Razer Kraken Kitty V2. From here, you can customize your device's settings to unleash its full potential. Changes made under this tab are automatically saved to your system and cloud storage.

#### Sound

The Sound subtab is for adjusting the overall system volume or individual volume of all active applications, and accessing Windows Sound properties.

SYNAPSE AUDIO PROFILES	¢ – 🗆 X
< > SOUND MIC LIGHTING	<b>9</b>
PROFILE RZB-SI	E133-Default • ···
VOLUME 0 100 Volume Mixer	<ul> <li>7.1 SURROUND SOUND</li> <li>With your new Razer headset comes a new level of immersion with greater audio positioning.</li> <li>Download 7.1 Surround Sound and register your product to get your activation code sent to your email.</li> </ul>
SOUND PROPERTIES Open Windows Sound Properties	Cet started
RAZE	R KRAKEN KITTY V2

#### Profile

A Profile is a data storage for keeping all your Razer peripheral's settings. By default, the profile name is based on your system's name. To add, import, rename, duplicate, export, reset or delete a profile, press the Miscellaneous button (•••).

#### Volume

Adjust the audio volume of the device. You may also access the Windows volume mixer of the current playback device, where you can proportionally adjust the system's overall volume or individually adjust the volume of each active application.

#### Sound Properties

Launches the Windows Sound Properties window where you can manage your system's sound settings, such as modifying the playback and recording device settings, sound scheme, and default communications activity.

#### Activate the 7.1 Surround Sound\*

Experience accurate positional sound specifically designed for games, movies, and music.

- 1. Download the 7.1 Surround Sound software from <u>razer.com/7.1-surround-sound</u>.
- 2. Register your product at <u>razerid.razer.com/products</u> to get your activation code sent to your email.

\*Only available on Windows<sup>®</sup> 10 64-bit and above.

#### Mic

The Mic subtab enables you to change all outgoing mic audio settings.

3	SYNAPSE	AUDIO	PROFILES		¢ – 🗆 X
< >	SOUND	MIC	LIGHTING		•
	SOUND MICROPHONE MIC VOLUME		LIGHTING	PROFILE ZE-SG-E133-Default • •••	Ø
				RAZER KRAKEN KITTY V2	

#### Microphone

Adjust the microphone input for clearer mic audio, or mute the microphone using the slider.

### Mic Monitoring (Sidetone)

Enable this setting to monitor the microphone's raw audio input through the headset with an additional option to increase or decrease the audio monitoring volume.

#### Lighting

The Lighting subtab enables you to modify your Razer device's light settings.

	× – C ×
< > Sound Mic Lighting	• • • • • • • • • • • • • • • • • • •
PR	ROFILE RZB-SG-E133-Default • •••
BRIGHTNESS	EFFECTS     CONTRACTOR OF
SWITCH OFF LIGHTING	Quick effects are presets that can be saved to a device's profile and synced with other supported Razer Chroma-enabled devices
When display is turned Off When idle for (minutes)	STREAM-REACTIVE LIGHTING           Add a new level of audience interaction to your streaming. Program custom lighting effects that trigger during subscriber notifications, donations and more.           15         Learn More
	RAZER KRAKEN KITTY V2

#### Brightness

You can turn off your Razer device's lighting by toggling the Brightness option or increase or decrease its luminance using the slider.

#### Switch Off Lighting

This power-saving tool allows you to disable your device's lighting in response to your system's display turning off and/or automatically power down when your Razer Kraken Kitty V2 has been idle for a set time.

#### Quick Effects

Several quick effects can be selected and applied to your headset's lighting, as listed here:

_	Name	Description	How to set up
	Ambient awareness	The ears and earcups will reflect the averaged color on the selected screen region	Select a screen region

	Audio meter	The ears and earcups will light up according to the audio level with a default spectrum of colors	Select a Color Boost level
	Breathing	The lighting will fade in and out of the selected color(s)	Select up to 2 colors or randomize colors
B	Fire	The ears and earcups will light up in warm colors to mimic the motion of flames	No further customization required
	Spectrum cycling	The lighting will cycle between 16.8 million colors indefinitely	No further customization required
	Starlight	The ears and earcups will have a chance of fading in and out at a random time and duration	Select up to 2 colors or randomize colors and select a duration
	Static	The headset will remain lit in the selected color	Select a color
	Wave	The lighting will scroll in the direction selected	Select either left-to-right or right- to-left wave direction

If you have other supported Razer Chroma-enabled devices, you can synchronize their quick effects with your Razer device by clicking the Chroma Sync button (

**(**) Only devices that support the selected lighting effect will synchronize.

#### Advanced Effects

The Advanced Effects option allows you to choose a Chroma Effect you want to use on your Razer Chroma-enabled peripheral. To start making your own Chroma Effect, press the Chroma Studio button ( O CHROMA STUDIO ).

### Stream-Reactive lighting

Allow your headset's lighting to change dynamically based on integrated actions for different streaming services.



*The Chroma Connect module and the Streamer Companion app are required for this feature.* <u>Learn more about the Streamer Companion app</u>

### **PROFILES TAB**

The Profiles tab is a convenient way to manage all your profiles and link them to your games and applications.

#### Devices

View which games are linked to each device's profiles or which Chroma Effect is linked to specific games using the Devices subtab.



You can import Profiles from your computer or the cloud through the import button (  $\Box$ ) or create new profiles within the selected device using the add button ( + ). To rename, duplicate, export, or delete a profile, simply press the Miscellaneous button ( ••• ). Each profile can be set to activate when you run an application using the Linked Games option.

#### Linked Games

The Linked Games subtab allows you to add games, view devices linked to games, or search for added games. You can also sort games based on alphabetical order, last played, or most played. Added games will still be listed here, even if they are not linked to a Razer device.



To link games to connected Razer devices or Chroma Effects, simply click on any game from the list, and then click **Select a device and its profile to launch automatically during gameplay** to select the Razer device or Chroma Effect it will link with. Once connected, you may click the Miscellaneous button ( ••• ) of the corresponding Chroma Effect or device to select a specific Chroma Effect or profile.

### SETTINGS WINDOW

The Settings window, accessible by clicking the (  $\bigcirc$  ) button on Razer Synapse, enables you to configure the startup behavior and display language of Razer Synapse, control the recommendations you see on the Dashboard, check the firmware version and master guide of each Razer device, or perform a factory reset on any connected Razer device.

SYNAPSE AUDIO	PROFILES		¢ – 🗆 🗙
< > DASHBOARD			9
DEVICES      AZZER KRAKEN KITTY V      ONLINE SERVICES      ONLINE SERVICES      REGISTER YOUR RAZER PRO	<ul> <li>YOU MIGHT BE</li> <li>SETTINGS</li> <li>GENERAL</li> <li>DASHBOARD</li> <li>FIRMWARE</li> <li>RESET</li> <li>ABOUT</li> </ul>	AUTO-LAUNCH   Start Razer Synapse automatically when system starts   Note: Disabling Razer Synapse may affect your device's functionality.   Minimize to system tray on startup   THEME   Light   D ark   NOTFICATIONS   Image: Disabling and constructions   Display on-screen notifications   Display on-screen notifications   Display on-screen notifications	Razer support
RAZER GOLD & SILVER		VIEW MASTER GUIDE Razer Kraken Kitty V2 👼	

#### General tab

The General tab lets you change the software's display language, startup behavior, theme, and onscreen notifications. You may also manually sync your profiles to the cloud ( $\mathcal{C}$ ) or view the master guide of all connected Razer devices and installed modules.

#### Dashboard tab

Use the Dashboard tab to customize which Razer device recommendations based on your setup, and the games you play will appear on the Dashboard.

#### Firmware tab

Access the Firmware tab to view the current firmware version of your Razer device(s), and/or visit the Software and Firmware Update page to see whether a firmware update is available for your device(s).

#### Reset tab

The Reset tab allows you to perform a factory reset on all connected Razer devices with on-board memory and/or reset Razer Synapse tutorials to acquaint yourself again with Razer Synapse's new features on its next launch.



All profiles stored on the selected device's on-board memory will be erased when you reset a Razer device.

#### About tab

The About tab displays brief software information and copyright statement, and provides relevant links for its terms of use. You may also use this tab to check for software updates, or as quick access to Razer's social communities.

# 8. SAFETY AND MAINTENANCE

### SAFETY GUIDELINES

To achieve maximum safety while using your Razer Kraken Kitty V2, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to <u>support.razer.com</u> for assistance.

Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug the device to let the temperature stabilize to an optimal level.

We recommend stretching the headset gently apart before placing them over your head to minimize headband stress. However, please avoid overstretching the headset beyond its technical limits.

The device isolates external ambient sounds even at low volumes, resulting in lowered awareness of your external surroundings. Please remove the device when engaging in activities that require active awareness of your surroundings.

Listening to excessively loud volumes over extended periods can damage your hearing. Furthermore, legislation of certain countries permits a maximum sound level of 86db to affect your hearing for 8 hours a day. We, therefore, recommend that you reduce the volume to a comfortable level when listening for prolonged periods. Please, take good care of your hearing.

#### MAINTENANCE AND USE

The Razer Kraken Kitty V2 requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you clean the device using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents. When not in use, keep away the headset's mic foam from sunlight.

# 9. LEGALESE

### COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2023 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent, or other intellectual property right. The Razer Kraken Kitty V2 (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

#### LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit <u>razer.com/warranty</u>.

#### LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

#### GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.