


CYCPLUS

GPS BIKE COMPUTER G1



1. Package List



Bike computer x1



Bike computer mount x1



Rubber pad x1



Instruction manual x1



Rubber band x4




Micro USB
charging cable x1

2. About Installation


1. CYCPLUS Z1/Z2 bike computer mount
(Need to buy separately).

2. Use bike computer mount.




3. Specifications

Product Weight	56g
Battery	900mAh 3.7V
Charging Mode	Micro USB
Working time	35 hours
Charging Time	2 hours
Waterproof	IPX6 (Can resist high-pressure, heavy sprays of water.)



4. About Function

- Support GPS speed measurement, display Current/Max/Average Speed.
- Display Riding Time, Distance, Total Riding Time, ODO, O'clock, Altitude.
- Support setting ODO, Time Zone, Unit and Restoring Factory Settings.
- Device will automatically enter sleep mode after 10 minutes of inactivity, it will display your last cycling data when you turn it on.



5. About Buttons

		Power button ⏹	Setting button ⚙
Off state	Short press	Turn on	
On state	Short press	Switch Current/Average/Max Speed	Switch Time/Distance/Total Time/Odometer/Clock/Altitude
On state	Long press	Turn off	Enter/Exit setting

6. About Settings


There are 4 menus in settings (C4、C6、C7、C8) , in the display mode, long press the setting button to enter the setting mode. Short press the setting button to select setting menus. After setting, long press the setting button to return to the main menu.



Power on, long press the setting button to enter the setting mode



Short press the setting button to select desired setting



Short press the power button to enter the setting mode



Short press the setting button to edit the setting



Short press the power button to confirm the setting



Long press the setting button to return to the main menu

1. Time zone setting (C4)

After the screen displays C4, short press power button to confirm. The digit is blinking, then short press setting button to change the value and press power button to confirm.

2. Unit setting (C6)

After the screen displays C6, short press power button to confirm. The unit is blinking, then short press setting button to select the unit and short press the power button to confirm.

3. Factory reset (C7)

After the screen displays C7 , short press power button to confirm. After RECOVER starts blinking, press the setting button twice, the screen starts flashing, and it will automatically return to the display interface after three flashes.

4. Odometer setting (C8)

After screen displays C8 , short press the power button to confirm. After the number starts blinking, press the setting button to select the data fields and press the power button to confirm.

7. Factory Info

Manufacturer:

Chengdu Chendian Intelligent Technology Co., Ltd

Warranty:

Free replacement or repair within 1 year.

After sale email:

steven@cycplus.com



EUBRIDGE ADVISORY GMBH
Virginia Str. 2
35510 Butzbach,Germany
eubridge@outlook.com



TANMET INT'L BUSINESS LTD
9 Pantygraigwen Road, Pontypridd
Mid Glamorgan, CF37 2RR, UK
Tanmetbiz@outlook.com



FR

Cet appareil,
ses accessoires,
et batterie
se recyclent

À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCHETERIE

OU



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

MADE IN CHINA