

Wireless Noise Cancelling Gaming Headset

Reference Guide Guida di riferimento Videos Referenzanleitung Referenzvideo Referenzanleitung Referenzvideo

INZONE Buds Model: YY2977

START

https://rd1.sony.net/help/mdr/y2977h_zz/



5-053-591-14(1) ©2023 Sony Corporation Printed in Vietnam https://www.sony.net/

* 5 0 5 3 5 9 1 1 4 * (1)

SV VIETNAM YY2977

High volume may adversely affect your hearing. Do not use the unit while walking, driving, or cycling. Doing so may cause traffic accidents. Do not use in hazardous areas unless the product is designed for such use. If water or foreign matter enters the unit, it may result in fire or electric shock. If water or foreign matter enters the unit, stop use immediately and consult your nearest Sony dealer. In particular, be careful in the following cases:

- When using the unit near a sink or liquid container
- When using the unit outdoors, such as not falling into a sink or container filled with water.
- When using the unit in the rain or snow, or in other locations.

For details on the effects of contact with the human body from the mobile phone or other wireless devices connected to the unit, refer to the instruction manual for the wireless device.

If the earbud tips are not securely attached, they may fall off and remain inside the ear during use. Make sure that the earbud tips are securely attached before using the unit.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water) leakage, soft contact, or contact matter on the unit or charging cable, and cause an audio hiccup, headset malfunction, or other adverse effects. This product has magnets which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not use this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device. This product has magnets (for magnets or a magnet) used to secure the unit. If magnets (or a magnet) were swallowed, consult a doctor immediately. Keep this product away from children or other supervised individuals to prevent accidental ingestion. There is a danger that this unit or its small parts may be swallowed. After use, store the unit in the charging case and store in a location out of reach of small children.

Note about static electricity

If you use the unit when the air is dry, you may experience discomfort. Due to static electricity accumulated on your body, this is not a malfunction of the unit. You can reduce the effect by wearing clothes made of natural materials that do not easily generate static electricity.

For customers in the UK

STATEMENT OF COMPLIANCE

1. Model No. YY2977

2. Name and address of the manufacturer's authorised representative: Sony Europe B.V., The Heights, Brooklands, Weybridge, Surrey KT13 0XW, United Kingdom

3. This statement of compliance is issued under the sole responsibility of the manufacturer: Sony Corporation, 1-7-1 Honcho, Minato-ku Tokyo, 106-0075 Japan

4. Object of the statement: Wireless Noise Cancelling Gaming Headset

5. The object of the statement described above is in compliance with the applicable safety requirements in Schedule 1 of S.I. 2023 No. 1007

6. Where applicable, references to the relevant standards used in relation to which compliance is claimed are as follows:

7. Dated: 2023-07-08

8. Authorised signatory: (Name and position): Note(s):

Hereby, Sony Corporation declares that this equipment is in compliance with Directive 2014/53/EU (ErC) (using a commercially available USB AC Adaptor)

Using built-in lithium-ion batteries (Product type: Li-ion battery, 3.85 V)

Operating temperature: 0 °C to 40 °C

Power consumption: Low power mode: 0.5 W or less * This unit enters Low power mode immediately after charging is completed when connected to the AC adaptor.

Mass: Approx. 6.5 g x 2 (Headset (including earbud and transmitter device))

Approx. 50 g (Charging case)

Included items: Wireless Noise Cancelling Gaming Headset (1) USB Type-C® cable (USB-A to USB-C®) (1) Charging case (1) Headset (including earbud and transmitter device) (1) Documents (1) (set)

Communication system: Bluetooth®

Operating frequency: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology

Maximum output power: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology: < 10 dBm

Design and specifications are subject to change without notice.

System requirements for battery charge using USB AC adaptor: A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more.

Trademarks: Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

macOS and Mac are trademarks of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. any use of such marks by Sony Group Corporation and its subsidiaries is under license.

Signed for and on behalf of: Sony Europe B.V.

• Sony and INZONE are registered trademarks or trademarks of Sony Group Corporation or its affiliates.

• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "*" marks are not specified.

Licenses

• This product contains software that Sony uses under a licensing agreement with the owner of its copyright. It was obligated to announce the contents of the license to the agreement with the owner of its copyright. Please access the following URL and read the contents of the license.

• Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Precautions

The two-dimensional code or the URL on the cover will help you access the help guide that describes useful notes or procedures in details.

On water resistant of the unit

- The charging case and the USB transmitter are not water resistant.
- Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions. Note the following cautions: Do not immerse the unit in water.

To maintain water resistant performance

Carefully note the precautions below to ensure proper use of the unit.

- Do not touch the unit forcibly into the sound output holes.
- Do not drop the unit into water, and do not use the unit while swimming.
- Do not allow the unit to remain wet in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.

On BLUETOOTH® communications

• Microwaves emitting from a Bluetooth device may affect the electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident: – in hospitals, near priority signaling in trains, near automatic doors, or near fire alarms.

• The audio playback on this unit may be delayed during the use of transmitting devices. Due to the characteristics of Bluetooth wireless technology. As a result, the sound may not be in sync with the image when viewing movies or playing games.

On charging the unit

- Be sure to use the supplied USB Type-C cable.
- Be sure to use the supplied USB Type-C cable.
- After use, remove the headphones slowly. Do not pull the cord or the earbuds. If you are pulling the cords, forcibly pressing them in or quickly pulling them out can result in ear drum damage. When using the unit outdoors, the earbud diaphragm may produce a click sound. This is not a malfunction.

Other notes

- Do not experience discomfort while using the unit, stop using it immediately.
- If you have any questions or problems concerning this unit that are not covered in this manual, please contact your nearest Sony dealer.

Specifications

Headset

Power source: Wireless Noise Cancelling Gaming Headset (1) Using a commercially available USB AC Adaptor)

Using built-in lithium-ion batteries (Product type: Li-ion battery, 3.85 V)

Operating temperature: 0 °C to 40 °C

Power consumption: Low power mode: 0.5 W or less * This unit enters Low power mode immediately after charging is completed when connected to the AC adaptor.

Mass: Approx. 6.5 g x 2 (Headset (including earbud and transmitter device))

Approx. 50 g (Charging case)

Included items: Wireless Noise Cancelling Gaming Headset (1) USB Type-C® cable (USB-A to USB-C®) (1) Charging case (1) Headset (including earbud and transmitter device) (1) Documents (1) (set)

Communication system: Bluetooth®

Operating frequency: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology

Maximum output power: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology: < 10 dBm

Design and specifications are subject to change without notice.

System requirements for battery charge using USB AC adaptor: A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more.

Trademarks: Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

macOS and Mac are trademarks of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. any use of such marks by Sony Group Corporation and its subsidiaries is under license.

Signed for and on behalf of: Sony Europe B.V.

• Sony and INZONE are registered trademarks or trademarks of Sony Group Corporation or its affiliates.

• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "*" marks are not specified.

Licenses

• This product contains software that Sony uses under a licensing agreement with the owner of its copyright. It was obligated to announce the contents of the license to the agreement with the owner of its copyright. Please access the following URL and read the contents of the license.

• Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Precautions

The two-dimensional code or the URL on the cover will help you access the help guide that describes useful notes or procedures in details.

On water resistant of the unit

- The charging case and the USB transmitter are not water resistant.
- Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions. Note the following cautions: Do not immerse the unit in water.

To maintain water resistant performance

Carefully note the precautions below to ensure proper use of the unit.

- Do not touch the unit forcibly into the sound output holes.
- Do not drop the unit into water, and do not use the unit while swimming.
- Do not allow the unit to remain wet in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.

On BLUETOOTH® communications

• Microwaves emitting from a Bluetooth device may affect the electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident: – in hospitals, near priority signaling in trains, near automatic doors, or near fire alarms.

• The audio playback on this unit may be delayed during the use of transmitting devices. Due to the characteristics of Bluetooth wireless technology. As a result, the sound may not be in sync with the image when viewing movies or playing games.

On charging the unit

- Be sure to use the supplied USB Type-C cable.
- Be sure to use the supplied USB Type-C cable.
- After use, remove the headphones slowly. Do not pull the cord or the earbuds. If you are pulling the cords, forcibly pressing them in or quickly pulling them out can result in ear drum damage. When using the unit outdoors, the earbud diaphragm may produce a click sound. This is not a malfunction.

Other notes

- Do not experience discomfort while using the unit, stop using it immediately.
- If you have any questions or problems concerning this unit that are not covered in this manual, please contact your nearest Sony dealer.

Specifications

Headset

Power source: Wireless Noise Cancelling Gaming Headset (1) Using a commercially available USB AC Adaptor)

Using built-in lithium-ion batteries (Product type: Li-ion battery, 3.85 V)

Operating temperature: 0 °C to 40 °C

Power consumption: Low power mode: 0.5 W or less * This unit enters Low power mode immediately after charging is completed when connected to the AC adaptor.

Mass: Approx. 6.5 g x 2 (Headset (including earbud and transmitter device))

Approx. 50 g (Charging case)

Included items: Wireless Noise Cancelling Gaming Headset (1) USB Type-C® cable (USB-A to USB-C®) (1) Charging case (1) Headset (including earbud and transmitter device) (1) Documents (1) (set)

Communication system: Bluetooth®

Operating frequency: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology

Maximum output power: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology: < 10 dBm

Design and specifications are subject to change without notice.

System requirements for battery charge using USB AC adaptor: A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more.

Trademarks: Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

macOS and Mac are trademarks of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. any use of such marks by Sony Group Corporation and its subsidiaries is under license.

Signed for and on behalf of: Sony Europe B.V.

• Sony and INZONE are registered trademarks or trademarks of Sony Group Corporation or its affiliates.

• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "*" marks are not specified.

Licenses

• This product contains software that Sony uses under a licensing agreement with the owner of its copyright. It was obligated to announce the contents of the license to the agreement with the owner of its copyright. Please access the following URL and read the contents of the license.

• Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Precautions

The two-dimensional code or the URL on the cover will help you access the help guide that describes useful notes or procedures in details.

On water resistant of the unit

- The charging case and the USB transmitter are not water resistant.
- Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions. Note the following cautions: Do not immerse the unit in water.

To maintain water resistant performance

Carefully note the precautions below to ensure proper use of the unit.

- Do not touch the unit forcibly into the sound output holes.
- Do not drop the unit into water, and do not use the unit while swimming.
- Do not allow the unit to remain wet in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.

On BLUETOOTH® communications

• Microwaves emitting from a Bluetooth device may affect the electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident: – in hospitals, near priority signaling in trains, near automatic doors, or near fire alarms.

• The audio playback on this unit may be delayed during the use of transmitting devices. Due to the characteristics of Bluetooth wireless technology. As a result, the sound may not be in sync with the image when viewing movies or playing games.

On charging the unit

- Be sure to use the supplied USB Type-C cable.
- Be sure to use the supplied USB Type-C cable.
- After use, remove the headphones slowly. Do not pull the cord or the earbuds. If you are pulling the cords, forcibly pressing them in or quickly pulling them out can result in ear drum damage. When using the unit outdoors, the earbud diaphragm may produce a click sound. This is not a malfunction.

Other notes

- Do not experience discomfort while using the unit, stop using it immediately.
- If you have any questions or problems concerning this unit that are not covered in this manual, please contact your nearest Sony dealer.

Specifications

Headset

Power source: Wireless Noise Cancelling Gaming Headset (1) Using a commercially available USB AC Adaptor)

Using built-in lithium-ion batteries (Product type: Li-ion battery, 3.85 V)

Operating temperature: 0 °C to 40 °C

Power consumption: Low power mode: 0.5 W or less * This unit enters Low power mode immediately after charging is completed when connected to the AC adaptor.

Mass: Approx. 6.5 g x 2 (Headset (including earbud and transmitter device))

Approx. 50 g (Charging case)

Included items: Wireless Noise Cancelling Gaming Headset (1) USB Type-C® cable (USB-A to USB-C®) (1) Charging case (1) Headset (including earbud and transmitter device) (1) Documents (1) (set)

Communication system: Bluetooth®

Operating frequency: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology

Maximum output power: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology: < 10 dBm

Design and specifications are subject to change without notice.

System requirements for battery charge using USB AC adaptor: A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more.

Trademarks: Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

macOS and Mac are trademarks of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. any use of such marks by Sony Group Corporation and its subsidiaries is under license.

Signed for and on behalf of: Sony Europe B.V.

• Sony and INZONE are registered trademarks or trademarks of Sony Group Corporation or its affiliates.

• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "*" marks are not specified.

Licenses

• This product contains software that Sony uses under a licensing agreement with the owner of its copyright. It was obligated to announce the contents of the license to the agreement with the owner of its copyright. Please access the following URL and read the contents of the license.

• Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Precautions

The two-dimensional code or the URL on the cover will help you access the help guide that describes useful notes or procedures in details.

On water resistant of the unit

- The charging case and the USB transmitter are not water resistant.
- Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions. Note the following cautions: Do not immerse the unit in water.

To maintain water resistant performance

Carefully note the precautions below to ensure proper use of the unit.

- Do not touch the unit forcibly into the sound output holes.
- Do not drop the unit into water, and do not use the unit while swimming.
- Do not allow the unit to remain wet in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit in water or use it in the rain.
- Do not use the unit in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.

On BLUETOOTH® communications

• Microwaves emitting from a Bluetooth device may affect the electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident: – in hospitals, near priority signaling in trains, near automatic doors, or near fire alarms.

• The audio playback on this unit may be delayed during the use of transmitting devices. Due to the characteristics of Bluetooth wireless technology. As a result, the sound may not be in sync with the image when viewing movies or playing games.

On charging the unit

- Be sure to use the supplied USB Type-C cable.
- Be sure to use the supplied USB Type-C cable.
- After use, remove the headphones slowly. Do not pull the cord or the earbuds. If you are pulling the cords, forcibly pressing them in or quickly pulling them out can result in ear drum damage. When using the unit outdoors, the earbud diaphragm may produce a click sound. This is not a malfunction.

Other notes

- Do not experience discomfort while using the unit, stop using it immediately.
- If you have any questions or problems concerning this unit that are not covered in this manual, please contact your nearest Sony dealer.

Specifications

Headset

Power source: Wireless Noise Cancelling Gaming Headset (1) Using a commercially available USB AC Adaptor)

Using built-in lithium-ion batteries (Product type: Li-ion battery, 3.85 V)

Operating temperature: 0 °C to 40 °C

Power consumption: Low power mode: 0.5 W or less * This unit enters Low power mode immediately after charging is completed when connected to the AC adaptor.

Mass: Approx. 6.5 g x 2 (Headset (including earbud and transmitter device))

Approx. 50 g (Charging case)

Included items: Wireless Noise Cancelling Gaming Headset (1) USB Type-C® cable (USB-A to USB-C®) (1) Charging case (1) Headset (including earbud and transmitter device) (1) Documents (1) (set)

Communication system: Bluetooth®

Operating frequency: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology

Maximum output power: Bluetooth: 2.400 MHz - 2.483,5 MHz * 2.4 GHz proprietary wireless technology: < 10 dBm

Design and specifications are subject to change without notice.

System requirements for battery charge using USB AC adaptor: A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more.

Trademarks: Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

macOS and Mac are trademarks of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. any use of such marks by Sony Group Corporation and its subsidiaries is under license.

Signed for and on behalf of: Sony Europe B.V.

• Sony and INZONE are registered trademarks or trademarks of Sony Group Corporation or its affiliates.

• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "*" marks are not specified.

Licenses

• This product contains software that Sony uses under a licensing agreement with the owner of its copyright. It was obligated to announce the contents of the license to the agreement with the owner of its copyright. Please access the following URL and read the contents of the license.

• Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Precautions

The two-dimensional code or the URL on the cover will help you access the help guide that describes useful notes or procedures in details.

On water resistant of the unit

- The charging case and the USB transmitter are not water resistant.
- Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions. Note the following cautions: Do not immerse the unit in water.

To maintain water resistant performance

Carefully note the precautions below to ensure proper use of the unit.

- Do not touch the unit forcibly into the sound output holes.
- Do not drop the unit into water, and do not use the unit while swimming.
- Do not allow the unit to remain wet in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe it any water after use.
- Do not place the unit

Nederlands

draadloze geluidsonderdrukkende gaming-headset

Model: 'Y2977

De trim 'Product' in dit document verwijst naar de aansluiting van naar de draadloze versie. Installeer het toestel niet in een krappe ruimte zoals een boekenrek of inbouwkast.

Siel de batterijen (batterijpakket of geïntegreerde batterijen) niet langer aansluiten op grote hite, zoals zonnenscherm, vuur of dergelijke. Siel de batterijen niet bloot aan zeer lage temperaturen (onder nul) en vermijd in thermische instabiliteit te voorkomen.

Demonteer, open of vernietig opblaadbare batterijen niet.

Repareer geen opblaadbare batterij lekken, laat de vloeistof dan niet in contact komen met de ogen of de huid. In geval van contact spoel het met water af. Gebruik niet met warm water en roep de hulp in van een arts.

Opblaadbare batterijen moeten voor gebruik worden opgeladen. Raadpleeg de instructies van de fabrikant of de gebruiksaanwijzing voor de juiste manier van opladen.

De draadloze versie van het hoofd zijn niet de opblaadbare batterijen mede verantwoord te laden en te ontladen om de maximale prestaties te worden verzekerd.

Kenningsgeving voor klanten: de volgende tekens en symbolen op de verpakking of op producten die wordt verkocht in landen/ regio's waar de EU-richtlijn van kracht is:

Dit product werd vervaardigd door of in opdracht van Sony Corporation.

EU-importeur: Sony Europe B.V., Rembrandtplein 1, 1017 CA Amsterdam, Nederland. Het merk betrekking tot Europeo productieformaat kunnen worden gericht aan de gemachtigde vertegenwoordiger van Sony Europe B.V. in het land waar de producten worden verkocht.

Dit product werd vervaardigd door of in opdracht van Sony Corporation.

EU-importeur: Sony Europe B.V., Rembrandtplein 1, 1017 CA Amsterdam, Nederland. Het merk betrekking tot Europeo productieformaat kunnen worden gericht aan de gemachtigde vertegenwoordiger van Sony Europe B.V. in het land waar de producten worden verkocht.

Batterijpakket:

Springpower

Springpower Technology (Shenzhen) Co., Ltd. Room 103-106, No.18 Futian Road, Zhuhai, China

VDL

Chongqing VDL Electronics Co., Ltd. Building 1-4, Puli Industrial New Area, Zhaojia Street, Kaizhou District, Chongqing, People's Republic of China

ZeinPower/ZeP

Zhuohui Zhi Li Battery Co., Ltd. Room 103-106, No.18 Futian Road, Zhuhai, China

Handelsmerken

Microsoft

Handelsmerken

Over de spatwaterbestendigheid van het toestel

Verwijering van oude batterijen, elektronische apparaten (van toepassing in de met auto's samenhangende landen)

Over de spatwaterbestendigheid van het toestel

Behoud van de spatwaterbestendigheid

Licenties

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

Over de spatwaterbestendigheid van het toestel

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W

2-2,5 W