

# SPOTLIGHT 2

Setup Guide

Setup Guide



## CONTENTS

English . . . . . 3

Français . . . . . 13


Español (México). . . . . 23

Português (Brasil) . . . . . 33

繁體中文 . . . . . 43


한국어 . . . . . 53

**KNOW YOUR PRODUCT**



## WHAT'S IN THE BOX

1. Spotlight 2 Presenter
2. Logi Bolt *USB-C* receiver (inside the presentation remote)
3. User documentation



## SETUP

### STEP 1: TURN ON YOUR SPOTLIGHT 2 TO CONNECT IT

Remove the pull tab inserted next to Logi Bolt receiver. The LED will start blinking white rapidly, indicating pairing mode.

If there is no power, try to charge the remote for more than 1 minute.



### STEP 2: CHOOSE HOW YOU WANT TO CONNECT YOUR SPOTLIGHT 2

#### Connect with Logi Bolt wireless receiver


Remove the receiver from SPOTLIGHT 2 and plug it into a *USB-C* port on your computer. Press any button on the remote to power it on, and wait a moment while it automatically connects. When the connection is complete, the white LED will turn off.

#### ↔ logi bolt

1



2



## Connect with Bluetooth®

Go to *Bluetooth*® settings on your computer and select SPOTLIGHT 2 in the list of discovered devices. Once connected, the white LED will turn off.


Your remote should now be connected.

### Note:


To enter pairing mode again, press and hold the Back and Next buttons simultaneously for three seconds until the LED blinks rapidly.



1




2



## STEP 3: INSTALL LOGITECH OPTIONS+ SOFTWARE

To enable advanced highlighting effects and customizations download Logi Options+ for *Windows* or *macOS* at [app.logi.com](http://app.logi.com).



Logi App  
[app.logi.com](http://app.logi.com)

**Pointer:** Set pointer modes, customize the size of your highlighting effects, adjust pointer speed and more.

**Button press sensitivity:** Choose how much pressure you prefer for the highlighting button.


**Action button:** Configure the button to perform actions such as start/exit presentation mode, hide slides to draw audience attention, set smart actions, and more.

**Haptic feedback intensity:** Adjust the remote's haptic intensity and turn off some of the haptic alerts.

**Timer:** Track presentation time and set haptic alerts.

**Breathing experience:** Feel more focused, confident, and ready to present at your best.

**Onboarding:** Learn how to use Spotlight 2 with an immersive tour.



## CHARGING


When the presenter is at critical battery level (10% or below), the battery LED will blink red.

Connect one end of the charging cable (sold separately) to the USB-C port on the remote and the other end to a USB power source.

- Up to 90 days on full charge
- 1-minute quick charge will give you up to 3 hours of use


### Note:

Battery life may vary depending on user and operating conditions.




## RECYCLE / REPLACE BATTERY


1. Remove the USB receiver from the remote.




2. Use a flat-head screwdriver to pry off the rear cover at the small opening.




3. Loosen the two screws that hold the battery in place, then remove the battery.



4. Follow your local regulations and guidelines to dispose of the used battery at a designated collection point or recycling facility in your area.



5. To order a replacement battery, please visit iFixit.

 [logitech.com/recycling](https://www.logitech.com/recycling)  
[logitech.com/support/spotlight2](https://www.logitech.com/support/spotlight2)

## DIMENSIONS

### SPOTLIGHT 2

Height x Width x Depth:  
125 mm x 30 mm x 13.5 mm (4.92 in x 1.18 in x 0.53 in)

Weight:  
52.5 g (1.85 oz)

### Logi Bolt USB-C Receiver:

Height x Width x Depth:  
40.3 mm x 13.6 mm x 7 mm (1.59 in x 0.54 in x 0.28 in)

Weight:  
1.5 g

## SYSTEM REQUIREMENTS

### Logi Bolt USB-C Receiver

Required: Available *USB-C* port, *Windows* 10, 11, or later, *macOS* 14 or later, *ChromeOS\**, *Linux\**

### **Bluetooth® Low Energy**

*Windows* 10, 11, or later, *macOS* 14 or later, *ChromeOS\**, *Linux\**, *Android* 14 or later\*, *iPadOS* 17 or later\*

\* Device basic functions will be supported without software for other systems than *Windows* and *macOS*.

## TECHNICAL SPECIFICATIONS

### Connectivity

Wireless technology: Logi Bolt *USB-C* Receiver, *Bluetooth®* Low Energy

Wireless range: up to 30 m (with an open line of sight) / 100 ft

**Note:**  
Wireless range may vary depending on the operating environment and computer setup.

### Sensors

Sensor technology: Pressure, Gyro

### Buttons

Number of Buttons: 4 (next, back, highlight, action)

[www.logitech.com/support/spotlight2](http://www.logitech.com/support/spotlight2)

© 2026 Logitech. Logitech, Logi, Logi Bolt, and all other Logitech trademarks and logos are trademarks or registered trademarks of Logitech Europe S.A. or its affiliates in the U.S. and/or other countries. The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. *macOS* and *iPadOS* are trademarks of Apple Inc. This product works with devices capable of running the latest version of *ChromeOS* and has been certified to meet Google's compatibility standards. Google is not responsible for the operation of this product or its compliance with safety requirements. *Android*, *ChromeOS*, and *Chromebook* are trademarks of Google LLC. *Windows* is a trademark of the Microsoft Corporation. *Linux* is the registered trademark of Linus Torvalds in the U.S. and other countries. *USB-C* is a trademark of USB Implementers Forum. All other trademarks are the property of their respective owners.

© 2026 Logitech. Logitech, Logi, Logi Bolt, and all other Logitech trademarks and logos are trademarks or registered trademarks of Logitech Europe S.A. or its affiliates in the U.S. and/or other countries. The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. *macOS* and *iPadOS* are trademarks of Apple Inc. This product works with devices capable of running the latest version of *ChromeOS* and has been certified to meet Google's compatibility standards. Google is not responsible for the operation of this product or its compliance with safety requirements. *Android*, *ChromeOS*, and *Chromebook* are trademarks of Google LLC. *Windows* is a trademark of the Microsoft Corporation. *Linux* is the registered trademark of Linus Torvalds in the U.S. and other countries. *USB-C* is a trademark of USB Implementers Forum. All other trademarks are the property of their respective owners.

WEB-621-002876 00A